

Karbonn A6 Turbo 3G

User Manual

Table of Contents

1 Safety	3
1.1 Safety Precautions	3
1.2 Using your phone safely	5
2 Understanding your Phone	8
2.1 Your Phone.....	8
2.2 Description Icons	9
2.3 Charging the battery.....	9
2.4 Power ON/OFF	9
2.5 Enter Main Menu.....	10
2.6 Enter Sub Menu	10
2.7 Use Notification Panel	10
2.8 Expand Main Interface	10
2.9 Add icons on the main interface	11
2.10 Move icons on the main interface.....	11
2.11 Delete icons on the main interface.....	11
2.12 Change wallpapers	11
2.13 Install APK through File Manager.....	11
2.14 Camera.....	12
2.15 Play Store.....	12
2.16 Wi-Fi.....	13
3 Taking Care of your Device	14
4 Disclaimer	15

1 Safety

1.1 Safety Precautions



Please read through the following briefings carefully, and act in accordance with these rules, so as to prevent causing any danger or violating any law.

SAR Value

--Your mobile phone model has been designed to compile with applicable safety requirements for exposure to radio waves. The radio wave exposure guidelines employ a unit of measurement called Specific Absorption Rate (SAR). The recommended SAR limit for mobile handset is 1.6 W/Kg averaged over a 6 minutes period and taken over a volume containing a mass 1g of human tissue.

--The highest SAR value for this mobile phone model is **0.763 Watt/Kg** averaged over a 6 minutes period and taken over a volume containing a mass 1g of human tissue.

--Use cell phone when the signal strength is good. Keep your calls short or instead use headset or send a text message. This advice applies especially to children, adolescents and pregnant women.

--If you are using a Bluetooth headset device, please make sure it has a low power emitter.

ROHS Declaration

Declaration of Conformity with the requirements of the e-waste Management Rules, 2011 (adopted by Notification S.O.1035 (E) of Ministry of Environment and Forests)

The Product is in conformity with the requirements of Rule 13 of the e-waste Rules. The content of hazardous substance with the exemption of the applications listed in SCHEDULE II of the e-waste Rules:

1. Lead (Pb) – not over 0.1% by weight;
2. Cadmium (Cd) – not over 0.01% by weight;
3. Mercury (Hg) – not over 0.1% by weight;
4. Hexavalent chromium (Cr6+) – not over 0.1% by weight;
5. Polybrominated biphenyls (PBBs) – not over 0.1% by weight;
6. Polybrominated diphenyl ethers (PBDEs) – not over 0.1% by weight.

1.2 Using your phone safely



On The Road

Using a phone while driving is illegal in many countries. Please follow local laws and drive safely at all times.



Near Sensitive Electronics

Don't use your phone near sensitive electronic equipment – particularly medical devices such as pacemakers – as it could cause them to malfunction. It can also interfere with the operation of fire detectors and other automatic-control equipment.

For more information about how your phone affects pacemakers or other electronic equipment, please contact the manufacturer or your local distributor.

Your phone may cause interference when used near TVs, radios or automated office equipment.



While Flying

Your phone can cause interference with aircraft equipment. So it's essential you follow airline regulations. And if airline personnel ask you to switch off your phone, or disable its wireless functions, please do as they say.



In Hospital

Your phone may interfere with the normal operation of medical equipment. Follow all hospital regulations and turn it off when you're asked to by posted warnings or medical staff.



At a Petrol Station

Don't use your phone at petrol stations. In fact, it's always best to switch off whenever you're near fuels, chemicals or explosives.



Around Water

Keep your phone away from water (or any other liquid). It's not a waterproof model.



Making Repairs

Never take your phone apart. Please leave that to the professionals. Unauthorized repairs could break the terms of your warranty.



Broken Antenna

Don't use your phone if the antenna is damaged, as it could cause injury.



Near Explosives

Turn off your phone in or near areas where explosive materials are used. Always obey local laws and turn off your phone when requested.



Emergency Calls

To make an emergency call your phone must be turned on and in an area where there's network coverage. Dial the national emergency number and press 'send'. Explain exactly where you are and don't hang up until help has arrived.



Working Temperature

The working temperature for the phone is between 0 Degree and 40 Degree Celcius. Please don't use the phone outside the range. Using the phone under too high or too low temperature might cause problems.



At very high volume, prolonged listening to a mobile phone can damage your hearing.

2Understanding your Phone

2.1 Your Phone



2.2 Description Icons

Icons	Descriptions	Icons	Descriptions
	Shows the phone's network signal strength.		Show the phone's battery capacity.
	Speaker has been activated.		You have unread SMS.
	Call on hold		USB storage Turned on.
	The ringing type is set on Vibration.		Flight Mode
	Wi-Fi is ON	H/G	Data network in use.
	You have missed calls.		Alarm is active.
	In call		

2.3 Charging the battery

The rechargeable Li-ion battery that comes with your phone is ready to be used, but is not charged. It is easy to do & can be done in 4 simple steps below:

1. Connect the charger to your phone, and plug it into a socket.
2. The battery indicator in the corner of the screen will scroll to show you it's charging.
3. When fully charged, the battery indicator will stop scrolling.
4. Disconnect the charger from your mobile, and unplug.

2.4 Power ON/OFF

Press the power key to power-ON/OFF the phone.

When you turn your phone on, it'll automatically check the SIM

and show the following information on screen:

- **Input SIM1 PIN:** If you've set a PIN for your SIM1.
-

Note:

The PIN is supplied with your SIM. Please replace it with your own PIN code as soon as possible. Enter the wrong PIN three times, and your SIM will be locked. Then you'll need to contact your network service provider to ask for a PUK code to unlock it. It is applicable for both the SIMs if you are using 2 SIM Cards.

2.5 Enter Main Menu

In Idle mode, press the Menu key to enter the main menu on the desktop and click the Home key to return.

2.6 Enter Sub Menu

Once at the main menu, click the icon to select the submenu, press **Back Key** to return to the previous menu, and press the **Home Screen** to return to the home screen.

2.7 Use Notification Panel

As a new notification appears in the notification area, slide down in the area to view the contents of the notification.

2.8 Expand Main Interface

The main interface may extend and exceed the screen width to provide more space for newly added shortcuts and tools.

Slide your finger horizontally on the main interface to extend to

the left or right area of the main interface.

2.9 Add icons on the main interface

You can long press the icon on the main menu until it's enlarged and the mobile phone vibrates, and copies the icons in the main menu to the main interface.

2.10 Move icons on the main interface

1. Long press the icon on the main interface until it's enlarged.
2. Drag the icon to the desired position and then release it.

2.11 Delete icons on the main interface

1. Long press the icon on the main interface until it's enlarged.
2. Drag the icon to "Remove" to delete it.

2.12 Change wallpapers

1. Long press "Touch screen" to open the menu.
2. Choose from "Wallpapers", and Select the wallpaper and press "Set wallpaper" to complete.

2.13 Install APK through File Manager

APK is a supported file format for the Android mobile operating system.

1. Please copy the downloaded APK file into the SD card, and

then insert the SD card into the phone.

2. In Idle mode, click Main Menu to enter the main menu.
3. Click “File Manager” to enter the directory of SD card.
4. Click the APK file you wish to install, and follow the installation wizard.


2.14 Camera

Allows you to click pictures anytime you want. Your smart phone has High Definition camera which ensures you always click good quality of pictures and stores them under the Gallery folder. In Camera, easily choose Camcorder to record Video Files.



2.15 Play Store

Log in to your Gmail account to view all the applications & download from lakhs of applications available under the Google Market called Play Store.



Note:

To use this app please connect to an internet connection.

2.16 Wi-Fi

Your Smart Phone supports Wi-Fi which allows you to connect with a Wireless connection. This is useful for surfing internet on phone

- a. Enter "Settings" interface & search Wi-Fi available networks. Select the network you want to connect to.

3Taking Care of your Device

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Always keep the small parts of the phone away from children.
- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use indoor chargers.

4Disclaimer

- 1.Karbonn Mobiles reserves all the rights to change the specifications and the content of this product without any prior information.
- 2.Some contents and services accessible through this device belong to third parties and are protected by copyright, patent, trademark and or other intellectual laws.
- 3.Third Party services may be terminated or interrupted at any time. Karbonn does not bear any responsibility or authority for the warranty or usage of these applications.
- 4.Never attempt to disassemble your phone. You alone are responsible for how you use your phone and any consequences of its use.
- 5.If you noticed your device is heating abnormally, kindly reduce Screen Brightness to moderate level.
- 6.Keep a check on running Apps, Network condition and Screen Brightness to avoid heavy battery drain.

7.Regularly clean Cache memory stored in Apps data for

smooth performance to avoid Phone Hang. Path is”:

- Settings> Device> Apps> Downloaded> Apps> Cache> Clear
Cache.

- Settings> Device> Apps> RAM/Running > Apps>Kill unused
running Apps.

8.Try to keep 25% space free in Downloaded and RAM/Running
memory space for better experience.

9.Keep a check, Apps to be download must fit device
configuration.